



IBM® System Storage™ Architecture and Configuration Guide for SAP® HANA™ Tailored Datacenter Integration

location of this document:

<http://www-03.ibm.com/support/techdocs/atmastr.nsf/WebIndex/WP102347>

isicc@de.ibm.com

Version 2.13 – November 2017





Table of Contents

1	Preface	3
2	IBM storage architecture for SAP HANA TDI.....	3
3	The central theme.....	4
4	Requirements.....	4
5	Installation of SUSE SLES or Red Hat	5
6	Setup of shared access for the /hana/shared/ directory	5
7	IBM System Storage sizing & configuration	5
8	Linux setup & tuning.....	11
9	SAN zoning and volume mapping	13
10	Setup of file systems for DATA and LOG	13
11	VMware VVols	14
12	Setup of /hana/shared/global.ini.....	15
13	hdbparam fileio parameter	15
14	SAP HANA High Availability setup with IBM System Storage	15
15	SAP HANA Disaster Recovery setup with IBM System Storage	16
16	SAP HANA backup with IBM Spectrum Protect.....	16
17	IBM FlashCopy backup for SAP HANA.....	16
18	Change History	16
19	Resources	17
20	Trademarks.....	18
21	Disclaimers.....	19



1 Preface

This paper is intended as an architecture and configuration guide to setup the IBM® System Storage™ for the SAP® HANA™ tailored datacenter integration (SAP HANA TDI) within a SAN environment.

This document has been written for IT technical specialists and architects, with advanced skill levels on SUSE® Linux™ Enterprise Server or RedHat LINUX® and IBM System Storage, with a focus on architecting and setting up an IBM System Storage environment for SAP HANA TDI. The SAP HANA TDI allows the SAP customer to use external storage to attach to the SAP HANA server.

This document provides the necessary information to select, verify and connect IBM System Storage to the SAP HANA server through a SAN (fiber channel) attached storage network. The recommendations in this guideline apply to both single node and scale out configurations, as well as Intel® or IBM POWER® based SAP HANA systems.

For a list of all storage systems certified for SAP HANA production please visit:

<http://global.sap.com/community/ebook/2014-09-02-hana-hard-ware/enEN/enterprise-storage.html>

2 IBM storage architecture for SAP HANA TDI

The IBM System Storage needs to be connected through a SAN network with the SAP HANA server. IBM recommends – but not requires – the use of the IBM Spectrum Virtualize (SAN Volume Controller, SVC) as virtualization layer, enabling to centralize the management of the storage systems, as well as to provide easily high availability and disaster recovery functionality, as well as IBM FlashCopy backup and tiered storage pooling. For smaller HANA TDI deployments you can also use the IBM Storwize, which is based on the same functions like the SVC, and inherits its advantages described above.

IBM Storage Systems are certified for SAP HANA TDI production:

- IBM Storwize family, model V5010, V5020, V5030, V7000, V9000 and IBM Spectrum Virtualize (SVC)
- IBM FlashSystem family, model FS900, V9000, A9000R
- IBM DS8870, DS8880

For non-prod SAP HANA systems, any storage system can be used.



3 The central theme

Below the generic workflow describes how to setup SAP HANA TDI with IBM storage:

- I. Verify all server & storage components and firmware requirements given by SAP are met
- II. Install SLES or Red Hat operating system on all SAP HANA nodes
- III. If required: setup NFS services for the SAP HANA shared directory
- IV. Setup SAN storage systems
- V. Create SAN zone for SAP HANA environment
- VI. On the storage systems map the storage volumes (LUNs) to all target SAP HANA nodes
- VII. Perform Linux setup and tuning, e.g. multipath, IO scheduler, ...
- VIII. On each LINUX host create the file systems for *SAP HANA data, log, shared*
- IX. Setup of */hana/shared/global.ini*
- X. Install and configure the SAP HANA software
- XI. Optional: HA, DR, and Backup considerations

4 Requirements

Before starting to deploy a SAP HANA TDI, ensure that the following key items have are in place:

- A SAN environment is required to attach IBM System Storage through fiber channel with the SAP HANA TDI nodes.
- SAP requires a storage validation for SAP HANA TDI according to their KPI (key Performance Indicators) – please contact SAP for further details.
- The SAP HANA nodes must be sized and configured according to SAPs specification (Bill of Material for SAP HANA node), in addition each SAP HANA TDI system needs to have min 2 FC ports, recommended are 4 FC ports.

Naming: The term “node” is use for a single HANA instance: if for instance 4 HANA instances are deployed on a single IBM POWER server, or 4 HANA instances are deployed into one single LPAR, then this reflects 4 nodes.



5 Installation of SUSE SLES or Red Hat

Install the Linux operating System accordingly to the SAP PAM for the chosen SAP HANA version, see SAP note <https://launchpad.support.sap.com/#/notes/1944799>

6 Setup of shared access for the /hana/shared/ directory

SAP HANA **scale-out** and HANA HA node fail-over require that the directory /hana/shared/ must be accessible from all nodes, else this directory can be setup as local file system from type xfs.

The shared access can be achieved most easily through NFS. If such setup does not already exist, one of the following options can be used to implement it:

- High Availability NFS service with DRBD and IBM Tivoli System Automation for Multiplatform (SA MP) with SUSE Linux Enterprise High Availability Extension 11.
- Highly Available NFS service with DRBD and Pacemaker with SUSE Linux Enterprise High Availability Extension.

Setup these systems according to the appropriate implementation guides, and make the NFS file system available on all HANA nodes, including the spare nodes.

Basic setup of NFS Server, add this line to /etc/exports

```
/hana/shared node1(fsid=0,crossmnt,rw,no_root_squash, sync,no_subtree_check)
node2(fsid=0,crossmnt,rw, ...) node3( ...
```

Basic setup of the HANA nodes (NFS clients), add this line to /etc/fstab

```
nfs-server:/hana/shared /hana/shared nfs rw,soft,intr,rsize=8192,wsiz=8192 0 0
```

7 IBM System Storage sizing & configuration

This section covers the evaluated storage options.

7.1 Recommended IBM System Storage combinations

To achieve the required storage performance according to SAP KPIs (key performance indicators) for SAP HANA TDI, one of the following configurations listed should be chosen – nevertheless all IBM systems listed can be used as stand-alone system as well, used for DATA and LOG.

IBM Spectrum Virtualized is referred as SVC.



Because IBM SVC, and for smaller configurations IBM Storwize, provisions volumes (LUNs) as a single volume type and single storage system, it will ease the administration of storage pool tiers with Flash, SSD, and HDD types; and optional tasks like setup of storage high availability, FlashCopy base backup, storage based mirroring, or storage maintenance.

IBM recommends the use of read intensive SSD (RI SSD), SSD or Flash Systems for any kind of workload; no HDD should be used anymore for online data.

Near line HDD (NL HDD) are suitable for archive data, or backup last-storage-pool.

7.2 IBM System Storage sizing

This chapter provides some general sizing guidelines.

All components of the SAN infrastructure must be configured to use a minimum 8GB link speed with 4 links. All listed storage configurations apply to active SAP HANA TDI nodes only; no additional storage configuration is required for any stand-by system. If SVC stretched cluster needs to be configured, all listed storage configuration must be doubled.

Maximal number of HANA production systems support per IBM System Storage – independent if SSD, RI SSD, or HDD are used:

IBM System Storage	# HANA Prod
Storwize V5000 (10/20/30)	8/10/12
Storwize V7000 (624)	16
FlashSystem V9000	48
FlashSystem A9000R	48
FlashSystem 900	12
DS8870	16
DS8880 (4/6/8)	16 / 32 / 48
SVC 2145/2147 DH8, one / four node pairs	12 / 48
SVC 2145/2147 SV1, one / four node pairs	25 / 100



7.3 RI SSD

Since 2016, IBM offers RI SDD for the Storwize product line, currently the capacity ranges from approx. 2 TB up to 15 TB per disk. RI stands for **Read Intensive**.

These RI SDD are specified with one drive-write per day (DWPD), meaning, one full overwrite of the entire capacity per day at maximum.

During lifetime of the RI SSD, the capacity utilization should not exceed 80%. If the utilization approaches this limit, additional capacity of the same kind and device capacity need to be added.

7.4 IBM storage performance sizing for HANA

This section provides sizing guideline how to size IBM storage for HANA.

If not stated otherwise (and if applicable), use distributed RAID 5 (e.g. for Storwize), or classical RAID 5 e.g. for DS8000 as 6+1+1.

IBM SAN Volume Controller

- SV1: Each IO group (two nodes) is able to handle 25 HANA nodes, a four IO-group cluster is able to handle 100 HANA nodes.
- DH8: Each IO group (two nodes) is able to handle 12 HANA nodes, a four IO-group cluster is able to handle 48 HANA nodes.

IBM Storwize (V5000 / V7000)

- 12 SSD or RI SSD for every 6 nodes, as Distributed RAID

IBM FlashSystem V9000

- One building block supports up to 12 HANA systems
- One building block is one IBM FlashSystem V9000 Control Enclosure (AC2) and one to four FlashSystem 900 (AE2) with 12 Flash Cards
- The maximum number of SAP HANA nodes is 48 by using 4 building blocks

IBM FlashSystem A9000R

- One building block supports up to 12 HANA nodes
- One building block is one Flash enclose and two Grid controllers
- The maximum number of SAP HANA nodes is 48 by using 4 building blocks

IBM FlashSystem 900

- Supports up to 12 HANA production nodes
- One Flash Module supports one HANA node, min 6 Flash modules required
It recommended to use always 12 Modules per FlashSystem



IBM DS8000 family

- 16 SSD (RI SSD, or Flash Drives) for every 8 nodes

7.5 Definitions of storage pools and volumes

The SAP HANA Data and Log have different I/O characteristics reflected by the different storage systems configurations as described earlier. This has to be applied by pooling the appropriate storage systems accordingly.

For all storage systems:



- Create 4 volumes for HANA DATA and 4 volume for HANA LOG, for each node
- Use minimum 8 VD if used as MDISKs for SVC, increase number by four, in case more capacity or more performance are needed (8,12,16, ...).

IBM SVC storage pool and VDISK definitions

- Create 4 VDISKs for HANA DATA and 4 VDISKs for HANA LOG, for each node
- Switch on VDISK caching

7.6 Layout of storage pools and storage volumes

The following diagrams show the relationship between Linux file system, LINUX LV, VG, and PV, and the Virtual Volumes (VD, VDISK) and Managed Disks (MD, MDISK, RAIDs/Arrays) of a Storage Systems.




7.7 IBM SVC cluster configuration

The picture below shows the principle require wiring for an IBM SVC cluster configuration. The picture shows a two IO-group configuration.

More details can be found in the IBM Redbook "Implementing the IBM System Storage SAN Volume Controller with IBM Spectrum Virtualize V7.8",

<https://www.redbooks.ibm.com/redbooks.nsf/RedbookAbstracts/sg247933.html?Open>



7.8 Competing storage utilization

Every IBM storage system can be shared between SAP HANA (production) and any other SAP or non-SAP (production) workload.

To do so proper sizing, the entire storage infrastructure needs be evaluated, including the configurations of RAID controller, number of HDD, SSD, or Flash Modules, number and type of HBA and FC ports/links.

IBM and IBM Business Partner are pleased to provide support for this sizing task, including the usage of the IBM storage sizing tools HANAmagic.



7.9 The use of IBM storage compression (RtC)

The IBM storage systems provide the option to compression data on VDISK / Volume level. Because the data of the HANA database are “just” integers, these data cannot be compressed much. RtC can be used, but the saving might be not high.

8 Linux setup & tuning

This section provides guides about the required setup and tuning, additional information can be found in guide “SUSE Linux Enterprise Server (12.x) for SAP Applications Configuration Guide for SAP HANA”:

<https://launchpad.support.sap.com/#/notes/1944799>

and Linux IO Tuning:

<https://www-03.ibm.com/support/techdocs/atsmastr.nsf/WebIndex/WP102584>

8.1 multipath

Here a sample configuration /etc/multipath.conf:

```
defaults {
    user_friendly_names    yes
}
devices {
    device {
        vendor              "IBM"
        product             "2145"
        path_grouping_policy group_by_prio
        prio                "alua"
        path_checker        "tur"
        Path_selector       "service-time 0"
        failback            "immediate"

        rr_weight           "priorities"
        no_path_retry       "fail"
        rr_min_io_rq        10
        dev_loss_tmo        600
        fast_io_fail_tmo    5
    }
}
```

(Parameter `rr_weight`: set to 'uniform' for HDD)

For using the SAP HANA fcClientLVM we recommend these settings to avoid hangs in the takeover:

- `no_path_retry = fail`

We recommend a retry setting of "fail" (or 0). This causes the resources to



fail over when the connection to the storage is lost. Otherwise, the messages queue and the resource failover cannot occur.

- `fast_io_fail_tmo = 5`
The `fast_io_fail_tmo` parameter sets the length of time to wait before failing I/O when a link problem is detected. I/O fails that want to reach the driver.
- `path_selector: service time 0`
A service-time oriented load balancer that balances I/O on paths according to the latency. This optimizes the SAP HANA Log I/O which is latency sensitive (as stated by Novell).

Using alias for UUIDs in `multipath.conf`

The `alias` setting overrules the `user_friendly_names` setting.

Using `alias` makes managing and identifying volumes easier. If you want to use `alias`, please make sure that in the case of a multi-node environment, you fully understand the requirement and handling of consistent multipath device names across all nodes: The `multipath.config` must be identical on all nodes (LINUX systems) belonging to the HANA instance.

```
multipaths {
    multipath {
        wwid          36006048000028350131253594d303030
        alias         HANA_ANA_DATA_1
    }
    multipath {
        wwid          36006048000028350131253594d303041
        alias         HANA_ANA_LOG_1
    }
}
```

8.2 IO device tuning

The following tunable parameters can be considered in case I/O performance issues have been detected. Do not change these in advance. Consult a performance specialist to find a vital combination:

- Increase `/sys/block/<device>/queue/nr_requests` if the default (128) results in blocked I/O submission. This will indirectly help to optimize the blocking inside SAP HANA.
- Increase `'rr_min_io_rq 32'` in `multipath.conf`
- Increase the queue depth of devices, e.g.
`echo 64 > cat /sys/bus/scsi/devices/<device>/queue_depth`



8.3 IO scheduler (elevator)

The default scheduler cfq delivers low IO performance for multiple (parallel) streaming read processes. The NOOP scheduler is recommended for setups with devices that do I/O scheduling themselves, such as intelligent storage or in multi-pathing environments. The DEADLINE scheduler can provide a superior throughput over the CFQ I/O scheduler in cases where several threads read and write and fairness is not an issue. For example, for several parallel readers from a SAN.

We recommend to use the **NOOP** scheduler for SAP HANA.

For more information, see SUSE System Analysis and Tuning Guide at <https://www.suse.com/documentation/sles11/>

9 SAN zoning and volume mapping

Apply standard, best practices zoning within the SAN.

If HANA High Availability node-fail over or HANA scale-out is use, then, and only then, it is required to map all Data and Log volumes to **all** SAP Hana Nodes.

10 Setup of file systems for DATA and LOG

Create the DATA, LOG, and SHARED file system needed by SAP HANA according to the *SAP HANA Storage Requirements* documentation from SAP.

- Use the **xfs** file system type with a 4KB block size for the DATA and LOG file systems
- To use LVM 2 use this schema:
vgcreate → lvreate → mkfs.xfs
- Use “useful” names for volume groups and logical volumes – do not use the hyphen (minus) sign ‘-’ as part of the name, because the LINUX mapper uses this sign as separator between VG and LV name.
- Create Volume Groups and Logical Volumes for DATA and LOG, for each HANA mount point (as listed in global.ini) create one Volume Group with exactly one Logical Volume.

It has turned out that these settings are most beneficial for SAP HANA workload in combination with SVC:

DATA

1. Use 4 PV for Volume Group DATA



2. Create a volume group with an extent size of 1MB and an alignment size of 1MB
`vgcreate vgcreate -s 1M --dataalignment 1M VG_ANA_DATA_1 /dev/mapper/WWID_1 /dev/mapper/WWID_2 ...`
3. Create a logical volume with a stripe size of 256KB
`lvcreate -i 4 -I 256K -l 100%VG -n LV_ANA_DATA_1 VG_ANA_DATA_1`
4. Create the file system
`mkfs.xfs -b size=4096 -s size=4096 /dev/mapper/VG_ANA_DATA_1-LV_ANA_DATA_1`
5. Mount the file system
`mount /dev/mapper/VG_ANA_DATA_1-LV_ANA_DATA_1 /hana/data/ANA`

LOG:

1. Use 4 PV for Volume Group LOG:
2. Create a volume group with an alignment size of 1MB
`vgcreate vgcreate -s 1M --dataalignment 1M VG_ANA_LOG_1 /dev/mapper/WWID_1 ...`
3. Create a logical volume with a stripe size of 256KB
`lvcreate -i 4 -I 256K -l 100%VG -n LV_ANA_LOG_1 VG_ANA_LOG_1`
4. Create the file system
`mkfs.xfs -b size=4096 -s size=4096 /dev/mapper/VG_ANA_LOG_1-LV_LOG_1`
5. Mount the file system
`mount /dev/mapper/VG_ANA_LOG_1-LV_ANA_LOG_1 /hana/log/ANA`

SHARED (local, non-failover):

1. Use 1 PV for Volume Group SHARED
2. Create a volume group:
`vgcreate vgcreate -s 1M --dataalignment 1M VG_SHARED /dev/mapper/WWID_1`
3. Create a logical volume (without striping)
`lvcreate -l 100%VG -n LV_SHARED VG_SHARED`
4. Create the file system
`mkfs.xfs -b /dev/mapper/VG_SHARED-LV_SHARED`
5. Mount the file system
`mount /dev/mapper/VG_SHARED-LV_SHARED /hana/shared`

If HANA scale-out or HA node fail-over is used, **do not** add the file system to `/etc/fstab`, mounting will be done by SAP HANA.

11 VMware VVols

The same setup applies like for LINUX native installation as described in chapter 10; the only deviation is that VMware™ (ESX® server) controls the SAN multipath, not the LINUX OS. The volumes are typically accessible under the path:

`/dev/sd...` instead of `/dev/mapper/...`



Please have a look in the IBM Redbook how to setup VMware VVols with IBM storage: <http://www.redbooks.ibm.com/abstracts/sg248328.html?Open>

12 Setup of /hana/shared/global.ini

A dedicated global.ini file (located in /hana/shared) is only needed if you want to use the node fail-over functionality provided by SAP HANA software and for HANA scale-out; else the HANA installer will create a global.ini file.

Enter the Logical Volume names as shown in directory /dev/mapper into /hana/shared/global.ini :

```
[communication]
listeninterface = .global

[persistence]
basepath_datavolumes = /hana/data/ANA
basepath_logvolumes  = /hana/log/ANA

[storage]
ha_provider           = hdb_ha.fcClientLVM
partition_*_*_prtype = 5
partition_1_data_lvmname = VG_ANA_DATA_1-LV_ANA_DATA_1
partition_1_log_lvmname  = VG_ANA_LOG_1-LV_ANA_LOG_1
partition_2_data_lvmname = VG_ANA_DATA_2-LV_ANA_DATA_2
partition_2_log_lvmname  = VG_ANA_LOG_2-LV_ANA_LOG_2
```

13 hdbparam fileio parameter

These parameter needs to be set for IBM Storage Systems:

```
async_write_submit_active : on
async_write_submit_blocks : all
async_read_submit         : on
```

For SAP HANA version 1 follow the instruction in SAP note "[1930979](#) - Alert: Sync/Async read ratio" how to set these parameters via the hdbparm tool.

For SAP HANA version 2 follow the instruction in SAP note "[2399079](#) - Elimination of hdbparam in HANA 2" how to set these parameters via HANA STUDIO.

14 SAP HANA High Availability setup with IBM System Storage

The SAP HANA system gains high availability through an N+1 concept – one or more server act as standby SAP HANA node – with dedicated storage for each active node. If one active SAP HANA node fails, the SAP HANA cluster software



initiates a failover to the standby node, and the standby node will mount the data and log from the failed node.

For more details, please read the SAP document [SAP HANA – High Availability](#).

To improve storage availability, IBM recommends to setup the storage environment as a SVC stretched cluster with symmetric VDISK mirroring.

15 SAP HANA Disaster Recovery setup with IBM System Storage

The disaster recovery capabilities of SAP HANA are documented on www.saphana.com:

- SAP HANA Scale-Out, High Availability & Disaster Tolerance
- SAP HANA – High Availability

If IBM Metro Mirror (synchronous) is used for storage replication for SAP HANA TDI, all DATA and all LOG volumes of all nodes from one HANA system must be included in **one** storage **Consistency Group**.

That implies (when using native attached storage) that both – Data and Log – must come from the same storage unit.

16 SAP HANA backup with IBM Spectrum Protect

IBM Spectrum Protect, also known as Tivoli Storage Manager for Enterprise Resource Planning (TSM for ERP) includes the package [Data Protection for SAP HANA®](#).

Please see current [product documentation](#) how to install, configure, and run this integrated solution.

17 IBM FlashCopy backup for SAP HANA

To minimize the backup and restore time IBM offers a solution that combines SAP HANA SNAPSHOT technology with IBM Spectrum Virtualize FlashCopy:

<https://www-03.ibm.com/support/techdocs/atmastr.nsf/WebIndex/WP102476>

18 Change History

V1	Initial version
V1.2	Update of chapter 7.9 to clarify files system setup



V1.3	Included new Storwize V5000
V1.4	Specified NFS section to be used only for /hana/shared/
V1.5	Minor updates – add some clarifications
V1.6	Add setup of multipath and global.ini
V1.7	Rework of document
V1.8	Added LINUX LVM2 & list of certified IBM storage systems
V2.1	Added IBM DS8000 system as certified for SAP HANA TDI
V2.2	Added IBM FlashSystem 900 & V9000
V2.3	Changes sizing rules, added recommendation for multipath and VG/LV settings.
V2.5	Changed /etc/multipath setting
V2.6	Added fileio parameter for hdbparam
V2.7	Added A9000R & DS8880; info on LINUX LVM settings for HANA LOG
V2.8	Added chapter on Storage RtC, changes in storage sizing
V2.9	Added paragraph about VMware VVols
V2.10	Updated multipath section
V2.11	Update default disk type to RI SSD.
V2.12	Storwize: New sizing, 4 PV for LOG VG

19 Resources

For any product or documentation provided by SAP please contact SAP.

For any product or documentation provided by SUSE please contact SUSE.

For any product or documentation provided by IBM regarding SAP send an email to isicc@de.ibm.com.

IBM documentations:

This document is ID [WP102347](#) on www.ibm.com

SAP HANA on IBM Power Systems and IBM System Storage – Guides
<http://www-03.ibm.com/support/techdocs/atmastr.nsf/WebIndex/WP102502>

IBM Storwize product manuals:
<http://www-01.ibm.com/support/docview.wss?uid=ssg1S7003318>

Installation, configuration and usage of IBM Spectrum Protect for ERP (V8)
https://www.ibm.com/support/knowledgecenter/SSER83_8.1.0/erp.common/welcome.html

SAP documentation:

Overview - SAP HANA tailored data center integration
<http://www.saphana.com/docs/DOC-3633>



FAQ - SAP HANA tailored data center integration
<http://www.saphana.com/docs/DOC-3634>

Introduction to High Availability for SAP HANA
<http://www.saphana.com/docs/DOC-2775>

Access to sapjam and documentation will be provided by SAP – the listed links only work after login: login first, then access the links.

SAP HANA Fiber Channel Storage Connector Admin Guide
SAP HANA Storage Requirements (Storage Whitepaper.pdf)
<https://jam4.sapjam.com/wiki/show/60549>

SAP HANA reference architecture
<https://jam4.sapjam.com/wiki/show/48495>

SAP HANA Bill of Material
<https://jam4.sapjam.com/wiki/show/48202>

Novell / SUSE documentation:

<https://www.suse.com/documentation/sles-12/>

Highly Available NFS Storage with DRBD and Pacemaker with SUSE Linux Enterprise High Availability Extension 11
https://www.suse.com/documentation/sle_ha/single-html/book_sleha_techguides/book_sleha_techguides.html

20 Trademarks

IBM, the IBM logo, and ibm.com are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. These and other IBM trademarked terms are marked on their first occurrence in this information with the appropriate symbol (® or ™), indicating US registered or common law trademarks owned by IBM at the time this information was published. Such trademarks may also be registered or common law trademarks in other countries. A current list of IBM trademarks is available on the Web at <http://www.ibm.com/legal/copytrade.shtml>

The following terms are trademarks of the International Business Machines Corporation in the United States, other countries, or both:



AIX®, BladeCenter®, DB2®, Global Business Services®, Global Technology Services®, GPFST™, IBM SmartCloud®, IBM®, Intelligent Cluster™, Passport Advantage®, POWER®, PureFlex™, RackSwitch™, Redbooks®, Redpaper™, Redbooks (logo) ®, System Storage®, System x®, System z®, Tivoli®, z/OS®.

The following terms are trademarks of other companies:

SAP, R/3, ABAP, BAPI, SAP NetWeaver, Duet, PartnerEdge, ByDesign, SAP BusinessObjects Explorer, StreamWork, SAP HANA, the Business Objects logo, BusinessObjects, Crystal Reports, Crystal Decisions, Web Intelligence as well as their respective logos are trademarks or registered trademarks of SAP AG in Germany or an SAP affiliate company.

Intel Xeon, Intel, Itanium, Intel logo, Intel Inside logo, and Intel Centrino logo are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Linux is a trademark of Linus Torvalds in the United States, other countries, or both.

SUSE is a registered trademark of SUSE Germany and Novell USA, other countries, or both. SLES is a trademark of SUSE Germany and Novell USA, other countries, or both.

Other company, product, or service names may be trademarks or service marks of others.

21 Disclaimers

This information was developed for products and services offered in Germany.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you



any license to these patents. You can send license inquiries, in writing, to: IBM Director of Licensing, IBM Corporation, North Castle Drive, Armonk, NY 10504-1785 U.S.A.

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law: INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product and use of those websites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Any performance data contained herein was determined in a controlled environment. Therefore, the results obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.



This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.